



Glass Preparation SOP

Window tint glass prep before film application

SOP · Version 1.0

Organization: _____

Document ID: glass-prep-sop

Effective Date: _____

Approved By: _____

Glass Preparation SOP

Window tint glass prep before film application

Purpose

Remove contamination that causes adhesion failure and visual defects on tinted glass.

Procedure

Step 1 — Initial clean

1. Spray glass with slip solution; squeegee loose debris
2. Scrape only with fresh blade if adhesive residue present — never on coated glass without verification

Step 2 — Scrub

1. Apply glass prep solution with scrub pad (dot matrix areas: light pressure)
2. Pay special attention to dot matrix, gaskets, and top edge

Step 3 — Squeegee and final wipe

1. Squeegee all solution from glass and gaskets
2. Final IPA or glass prep wipe — edge to center
3. Inspect under light — no streaks, fingerprints, or dust

Step 4 — Install window

1. Film must be laid within contamination-controlled timeframe
2. If delay exceeds 15 minutes — re-prep affected area

Related documents

Document	ID
Window Tint Master Install Manual — Ch 09	window-tint-master-install

