



SOP-201 — Vehicle Wash Procedure

Section 3: Installation Operations

SOP · Version 1.0

Organization: _____

Document ID: sop-201-vehicle-wash-procedure

Effective Date: _____

Approved By: _____

SOP-201 — Vehicle Wash Procedure

Forge Standard Operating Procedures v1.0

Section 3: Installation Operations

Purpose

Remove surface dirt safely before decontamination and film application.

Scope

All vehicles receiving PPF, wrap, TPU, or coating. Performed in designated wash zone.

Procedure

Pre-rinse

1. Rinse entire vehicle top-down with pressure washer — max 1200 PSI, 12" standoff.
2. Focus wheel wells and lower panels where grit accumulates.
3. Never spray directly at panel gaps or damaged paint.

Contact wash

1. Two-bucket method: clean soap solution + rinse bucket with grit guards.
2. Microfiber wash mitt only — no brushes on paint.
3. Work top-down; straight-line motion; rinse mitt between panels.

Dry & handoff

1. Blow dry door jambs, mirrors, and emblems with filtered air.
2. Microfiber towel dry — no dragging across dry panels.
3. Move to decon bay immediately or cover vehicle if delay exceeds 30 minutes.

Quality standards

- ☐ Zero towel scratches from wash process
- ☐ Vehicle enters decon within 2 hours of wash

Safety notes



Wet floors — cones and caution signs required in wash bay.

Related documents

Document	ID
Decontamination	sop-202-decontamination
Contamination Control	sop-202-decontamination

Revision history

Version	Date	Author	Changes
1.0	2026-07-23	Forge Operations	Initial release

Confidential — Skill Forge training operations.